

A collection of chrome bathroom fixtures. On the left is a single-lever faucet with a curved spout. In the center are two separate chrome knobs with cross-shaped handles. On the right is a chrome showerhead with a curved, adjustable arm.

Ensure that the mains water supply is off before installation.
Before making any inlet pipe connections, all supply pipes **MUST** be Thoroughly flushed to remove debris.
Failure to do this could result in damage to the cartridge and components or low flow from the mixer.

Mielőtt bármilyen műveletet végrehajtana, ellenőrizze, hogy a hálózati vízellátás ki van-e kapcsolva!

Kellő szélességű szerelőnyílást minden esetben készíteni kell!

Bármely bemeneti cső csatlakoztatása előtt az összes ellátó csövet alaposan ki KELL öblíteni a törmelékek eltávolítása érdekében. Ennek elmulasztása a kerámiabetét és az alkatrészek károsodását vagy a keverő alacsony áramlását okozhatja.

