


Beépítési útmutató

Kád- és zuhanycapterelekhez (fali zuhanyszett):



EN

Ensure that the mains water supply is off before installation. Screwing the 2 eccentrics (1) to the water supply, with the right wheelbase sign in the quote design. After, positioning the body mixer (2) with the help of the threaded caps (3). Install kit duplex (4), to the desired distance by the body. Connect the flexible pipe (5) at the two ends, at the hand shower (6) and at the body.

Open the water supplies and test that there are no leaks. *

* Before making any inlet pipe connections, all supply pipes MUST be thoroughly flushed to remove debris. Failure to do this could result in damage to the cartridge and components or low flow from the mixer.

HU

Mielőtt bármilyen műveletet végrehajtana, ellenőrizze, hogy a hálózati vízellátás ki van-e kapcsolva.

Csavarozza fel a 2 excentert (1) a vízellátásra, a jobboldalon megjelölt tengelytávnak megfelelően.

Ezt követően, helyezze fel a keverőtestet (2) a menetes kupakok (3) segítségével.

Helyezze fel a zuhanytartót (4) a keverőtesttől kívánt távolságra.

Csatlakoztassa a gégecső (5) két végét - a kézizuhanyhoz (6), valamint a keverőtesthez.

Nyissa meg a vízellátást és ellenőrizze, nincs-e szivárgás.*

*Bármely bemeneti cső csatlakoztatása előtt az összes ellátó csövet alaposan ki KELL öblíteni a törmelékek eltávolítása érdekében. Ennek elmulasztása a kerámiabetét és az alkatrészek károsodását vagy a keverő alacsony áramlását okozhatja.