



Beépítési útmutató
Fal alatti mosdócsaptelephez
Termékkód: 8472K



A BEÉPÍTÉSI MÉLYSÉG A BURKOLT FELÜLETHEZ KÉPEST ÉRTENDŐ!



EN

Before doing any operation, make sure that the water supply is turned off and that the pipes are free from impurities and limestone.

Before making any inlet pipe connections, all supply pipes MUST be Thoroughly flushed to remove debris. Failure to do this could result in damage to the cartridge and components or low flow from the mixer.

Make sure to have enough space to build-in the internal part, referring to the measure shown in the drawing. If so, prepare pipes for connection.

Connect the pipe to the internal part as shown, using hemp or another sealant on the threads to prevent leakages. Check the seals before embedding the built-in body.

Once walled the internal part, pull the protections to remove them.

Slide on the covering plate with spout, taking care not to lose or damage the plate seals. Insert the control handle on the stick of the cartridge, tighten the supplied screw.

HU

Mielőtt bármilyen műveletet végrehajtana, ellenőrizze, hogy a hálózati vízellátás ki van-e kapcsolva, valamint, hogy a csövek vízkőtől és szennyeződésektől mentesek.

Bizonyosodjon meg róla, hogy van-e elegendő hely a belsőegység beépítésére, hivatkozva a beépítési rajzon szereplő értékekre. A burkolt falsíknak e kettő jelzősáv közé kell esnie az optimális elhelyezés érdekében. Amennyiben igen, készítse elő a csöveket a csatlakoztatásra.

Csatlakoztassa a vízcsövet a kezelőegységekhez az ábrán látható módon, a szivárgás megelőzése érdekében használjon kendert vagy más tömítőanyagot. Ellenőrizze a tömítéseket, mielőtt behelyezi a kezelőegységet.

A kezelőegység befalazását követően távolítsa el a műanyag védőkupakokat.

Helyezze fel a takarórozettákat. Helyezze fel a kezelőkarokat a takarórozettákra, majd rögzítse a kart a mellékelt csavarral.

Bármely bemeneti cső csatlakoztatása előtt az összes ellátó csövet alaposan ki KELL öblíteni a törmelékek eltávolítása érdekében. Ennek elmulasztása a kerámiabetét és az alkatrészek károsodását vagy a keverő alacsony áramlását okozhatja.